

Tools Required: Fisheed screwisher, Philips screwisher, place, wire cutters, who shippers, electrical tape, safety glasses Light Source: (1) 120V LED \*1W DBIMABLE (4000Q.

Extracted Assessed Time: 15-30 minutes

Properation: Identify and impost all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or duragred, do not attempt to assemble, install, or operate the tidure. Contest customer service for replacement.

## **▲ Warnings and Cautions**

Turn off electricity at circuit breaker or main fuse box before trebalation. Consult a Sceneed electricien if in doubt.

These instructions are provided for your safety, it is very treportant you read them completely before treballing the folium.

We strongly recommend that a Sceneed, professional electricien perform the trebalation.

Discovered future from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.



