READ PRIOR TO ATTEMPTING INSTALLATION Always turn off main power before installation Installation should be carried out by your local electrician

🔺 WARNING - Risk of cuts. Some metal parts in the fixture may have sharp edges. To prevent cuts and scrapes, wear gloves when handling the parts.

🔺 AVERTISSEMENT - Risque de coupure. Certaines pièces métalliques de l'appareil peuvent avoir des arêtes vives. Pour éviter les coupures et les éraflures, portez des gants lors de la manipulation des pièces.

| PACKAGING CONTENT | S |
|------------------------------|---|
| A Set | |
| Torsion Springs | Medium Base Socket Adapter |
| <i>i i i i i i i i i i</i> | |
| (2) Mounting Screws Female I | deal Connector Lamp Replacement Marking |

| COMPATIBLE LUMINAIRES | | | |
|-----------------------|-----------------------|------------------------|--|
| | | | |
| | Compatible Luminaires | | |
| Ν | NLOCAC-6R345W | 6" CAMO LED Luminaire | |
| Ν | NLOCAC-8R345W | 8" CAMO LED Luminaire | |
| Ν | NLOCAC-11R345W | 11" CAMO LED Luminaire | |
| Ν | NELOCAC-6R30W | 6" ELO LED Luminaire | |
| Ν | NELOCAC-8R3OW | 8" ELO LED Luminaire | |
| Ν | NELOCAC-11R30W | 11" ELO LED Luminaire | |
| Ν | NELOCAC-6PR | 6" ELO+ LED Luminaire | |
| Ν | NELOCAC-8PR | 8" ELO+ LED Luminaire | |
| Ν | NELOCAC-11PR | 11" ELO+ LED Luminaire | |

RETROFIT INSTALLATIONS (5" OR 6" HOUSING)

NOTE: RETROFIT KIT REQUIRES HOUSINGS WITH TORSION SPRING HOLDERS

- 1. Remove the existing lamp and trim from recessed housing.
- 2. Place LAMP REPLACEMENT LABEL onto the housing where it's visible during installation.
- 3. Attach the bracket to the luminaire and insert the plugs to secure. (Figure 1)
- 4. Attach the torsion spring kit onto the luminaire using the screws provided. Adjust the width to fit into a 5" or 6" housing. (Figure 2)
- 5. Insert the luminaire wires into the female ideal connector (White Negative & Black Positive). (Figure 3)
- 6. Screw the E26 socket adapter into socket of the housing. (Figure 4)
- 7. Squeeze the torsion springs to insert the luminaire into the housing. (Figure 5)
- 8. Installation complete.











