Assembly Instruction Sheet #IS-7148W4-S For Style 7148W4-S

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (1) 120V LED *1W DIMMABLE (4000K)

Estimated Assembly Time: 10-20 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement

Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture.

We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Package Contents



A Fixture Body x1

STEP 1 - Attach Mounting Screws, Lock Washers and Hex Nuts to Crossbar. A. Line up a set of holes on the

Crossbar (EE) and Holes on the Backplate. Thread Mounting Screws (DD

into the holes on the Crossbar (EE). Pass Lock Washers and thread Hex Nuts onto the Mounting

Screws (DD) Hand tighten until snug.

Ceiling **C**anopy Figure 1


Hardware Contents

PART	DESCRIPTION	

AA Mounting Screw 2pcs BB Electrical Marrets 2pcs


CC Outlet Box Screw 2pcs

DD Crossbar 1pcs



STEP 2 - Attach Crossbar to Outlet Box.

A. Pass the supply wires through the Crossbar (DD). Attach the Crossbar (DD) to the Outlet Box (CC) with the head of the Green Ground Screw facing you. Secure it with Outlet Box



Supply Wires with Outlet Box Screws Ground Wire