

LED Wallpack

VLWP-045 VLWP-070 VLWP-100



Up to 110lm/w Easy installation bracket(Option) More compact,45w/70w/100w in one enclosure Photocell control(Option) Dark bronze,dirt-resistant





Technical Parameter

	i i		1				
Modle	Color	Lumen	Beam Angle	LED	Power(W)	Input	CRI
VLWP-045-AW-W-01	White	4600	120	324pcs	45	AC 100-277V	80
				0.2w 2835	-	50-60Hz	
VLWP-045-AW-NW-01	Neutral White	4500	120	324pcs	45	AC 100-277V	80
				0.2w 2835		50-60Hz	
VLWP-045-AW-WW-01	Warm White	4100	120	324pcs	45	AC 100-277V	80
				0.2w 2835		50-60Hz	
VLWP-070-AW-W-01	White	7600	120	168pcs	70	AC 100-277V	80
				1W 2835		50-60Hz	
VLWP-070-AW-NW-01	Neutral White	7500	120	168pcs	70	AC 100-277V	80
				1W 2835		50-60Hz	
VLWP-070-AW-WW-01	Warm White	7000	120	168pcs	70	AC 100-277V	80
				1W 2835		50-60Hz	
VLWP-100-AW-W-01	White	10500	120	228pcs	100	AC 100-277V	80
				1W 2835		50-60Hz	
VLWP-100-AW-NW-01	Neutral White	10200	120	228pcs	100	AC 100-277V	80
				1W 2835		50-60Hz	
VLWP-100-AW-WW-01	Warm White	9500	120	228pcs	100	AC 100-277V	80
				1W 2835		50-60Hz	

Notice:

Lumen tolerance ±10% Power tolerance ±10% Photocell sensor: 120V/220V/277V

Modle Slection Guidance

Example:

VLWP-045-AW-WW -XX

XX could be 01,02,11,12

11:Normal type 0.5m with cable and mounting bracket

12:Normal type with photocell


01:UL type with no cable or mounting bracket

02:UL type with photocell




Application

Parking area, garden, backyard, walkway,passway,tunnel etc...





Dimension:



VLWP-045/VLWP-070/VLWP-100

Package Information

Net Weight										
VLWP-045	3.2KG	VLWP-070	3.4KG	VLWP-100 4.1	KG					
Gross We	ight									
VLWP-045	4.1KG	VLWP-070	4.3KG	VLWP-100	5.0KG					
Package Dimension										
VLWP-045	390*32	390*320*260(mm)								
VLWP-070	390*32	20*260(mm)								
VLWP-100	390*32	20*260(mm)								



Installation instructions

Normal type installation





Figure 1



1.As Figure 2 shows, confirm wiring direction and adjust position of fastening feet








Figure 4

2.Punch mounting holes in wall according to Figure 3












4. The screw components fix back cover to position of plastic fittings



5.Take upper cover apart,thread AC wire through back cover ,connect to power input wire,install upper cover and back cover(power need to be hidden inside of lamp body)

UL type installation






3 1/4" or 4" standard junctionbox hole

1.Drill 3 holes(if with junctionbox ,please drill 4 holes) on back cover according to **Figure 7**






4. Thread conduit from back and mounted the back cover to wall.(Mounted the back cover to wall then thread conduit from side)Make the optic connection (Driver output and LED input) before connect AC line.

5. Tie up the screws between upper cover and back cover

Wire diagram with photocell





Installation requirement

- 1. This luminaire is designed for wall-mount, do not mount it on celling or ground.
- 2.Make sure the power is cut off before installation;
- 3. Make sure the wall is thick and tough enough to hold the luminaires;

! Warnings

- 1.Refer to the specification and instruction before installation;
- 2. Make sure the luminaire is connected to the referenced voltage;
- 3. The luminaire must be installed by professional electrician;
- 4.If the enclosure or cable is broken ,do not try to install or repair,
- please contact the manufactory or local agency.